


## QuickStart











FC 3 Cordless  
FC 3 Cordless Premium



### A



### B



### C



### D

